

FIG. 2 50 -60 12 11 52 BAR CODE **~65** TRANS-MITTER PRESSURE SENSOR PRESSURE MONITOR ECU RUNNING STATE RECE I VER -70 DISPLAY PRESSURE SENSOR TRANS-**RECEIVER** 20 22 21

FIG. 3



